

COOLER ERROR CODES	
Error 30 FAN_LIMP	No fan speed signal detected. Motor will run at full speed
Error 40 Lo Water Fail	Cannot detect low water sensor.
Error 50 Hi_Lo Fail	Cannot detect high or low water sensor.
Error 41 Hi Water Fail	Cannot detect High water sensor.
Error 42 Drain_fail	Servo seal closed but water detected in tank
Error 60 MOTOR O-C	Motor failure